


PVC Dripline Start Connectors Single Male Thread*

	Size	Cat. No.	Packing
	1/2" Male	GSM12	1,100
	3/4" Male	GSM34	850

* Including Rubber Grommet EPDM (Catalog Number: G-16)

Elbow Ring*

	Size	Cat. No.	Packing
	16,5 (Black ring)	GET	800
	16;17 (Long ring)	GETL	800

* Including Rubber Grommet EPDM (Catalog Number: G-16)

PVC Dripline Start Connectors Double Y*

	Size	Cat. No.	Packing
	16 x 16	GY16	1,000


* Including Rubber Grommet EPDM (Catalog Number: G-16)

PVC Dripline Start Connector Elbow*

	Size	Cat. No.	Packing
	16mm	GE16	1,200
	17mm	GE17	1,200
	20mm	GE20	1,200

* Including Rubber Grommet EPDM (Catalog Number: G-16)

PVC Dripline Start Connectors Double Tee*

	Size	Cat. No.	Packing
	16mm	GD16	900
	17mm	GD17	1,000
	20mm	GD20	800


* Including Rubber Grommet EPDM (Catalog Number: G-16)

- Minimum quantity may apply, please inquire

Grommet Drill

	Size	Cat. No.	Packing
	15,5mm	GD155	NET
	16mm	GD160	NET
	16,5mm	GD165	NET

PVC Start Assembler

	Size	Cat. No.	Packing
	All sizes	GIND	NET

PVC Start Connectors Assembly Instructions

1. Drill hole: for PVC 16mm or 16.5mm diameter, for P.E 15.5mm diameter
2. Insert rubber grommet
3. Moisten starter
4. Insert starter with PVC start assembler by pushing **without twisting or turning**
5. Push leader pipe on barb connector. **Do no twist or turn the starter**

